



# Brava™

## Brava™ Wallcovering Materials Installation Instructions

### WALL PREPARATION:

The wall must be clean, dry, smooth, and free of dust and moisture. The wall should be a solid uniform light color for best results.

**NEW CONSTRUCTION:** Wipe down walls to ensure that there is no dust and apply a precoat primer. (As recommended by the manufacturer)

**EXISTING CONSTRUCTION:** Thoroughly clean the surface of walls to remove all dirt, grease, and imperfections in the wall to ensure it is a smooth surface.

- Remove old wallpaper and loose paint before washing the walls with water and degreaser.
- Fill in cracks and holes with a filler. Smooth out rough spots on the surface of the wall. (If plaster walls use a plaster-based filler).
- The wall must not be exposed to moisture. Prime absorbent walls with a solvent-free primer and apply an underlay for walls that are too absorbent.
- Only apply wallcovering to completely dry walls, otherwise, discoloration may occur, and adhesion will not be optimal.

### PASTE:

It is recommended to use paste for nonwoven wallcoverings, such as Metyl Special for Europe and Romans Pro 838 for the US, with the addition of 20% dispersion adhesive

### PRODUCT INSTALLATION:

All cuts are to be done with a sharp, new blade every time.

1. Always check the product for faults before hanging and check for faults as the strips are being hung. If any faults are visible, stop the work and contact the manufacturer.
2. Cut strips to the desired length, roll the printed side inwards.
3. It is recommended to use an adhesive for a nonwoven, that the average quantity of +/-200 g/m<sup>2</sup> or +/-5.90 oz/yd<sup>2</sup>. (Follow instructions from the paste manufacturer).
4. Apply the paste to the wall over a surface of 1 to 3 strips, depending on the degree of the wall absorption. Spread the paste evenly with a medium roller.
5. Roll the strip and place the top against the pasted wall. Then unroll the strip from the top downwards against the pasted wall. Rub the strip evenly using a rubber roller.
6. Install the strips on the wall next to each other without overlapping and press the strips down with a brush.
7. To expel any air bubbles, press down on the nonwoven with a plastic trowel or paperhanging brush.
8. Using a sharp box cutter and a wallpaper trimmer, cut the surplus material from the top and bottom.
9. Directly remove excess paste or any stains by dapping with a damp clean cloth or sponge. (Only water no chemicals). Repeat after hanging each strip. Then wipe with a dry cloth.
10. Always finish hanging wallcovering on one wall before starting the next.
11. Only hang rolls with the same batch number next to each other. Always avoid creases when hanging the material.
12. Use a seam roller to press down the seams of the wallcovering. Be sure to keep the roller clean.

ecological fibers, inc.

ENVIRONMENTALLY SOUND COVER SOLUTIONS

730 YORK AVENUE PAWTUCKET, RHODE ISLAND 02861 USA  
TEL: (401) 725 9700 FAX: (401) 724 4970 INFO@ECOFIBERS.COM  
WWW.ECOFIBERS.COM